

**Model 2950-2960**  
**Leveling System**  
**Operator's Manual**  
(D-020903CLA01B)



# TABLE OF CONTENTS



## 2000 Series Operator's Manual Model 2950-2960 Leveling Systems

SERIAL NUMBER LOCATION .....2

WARRANTY REGISTRATION .....3

WARRANTY POLICY.....4

SAFETY.....6

    SAFETY ALERT SYMBOL .....6

    OPERATION SAFETY.....7

    HYDRAULIC SAFETY.....7

    SERVICING AND MAINTENANCE SAFETY .....7

        USE PROPER TOOLS .....8

        HIGH PRESSURE FLUIDS .....8

        SUPPORT MACHINE PROPERLY .....8

        REMOVE KEY .....8

        USE PROPER LIFTING EQUIPMENT .....9

        REMOVE ALL SPILLED FLUIDS .....9

    SAE CODE 62 FOUR BOLT FLANGE FITTING TORQUE CHART .....9

    O-RING FACE SEAL FITTING TORQUE CHART .....11

    HIGHWAY OPERATION AND TRANSPORT SAFETY .....12

    SAFETY LABELS .....12

    SAFETY LABEL LOCATIONS.....13

    SAFETY LABEL SPECIFICATIONS.....14

OPERATION, SETUP, AND MAINTENANCE .....15

    ELECTRICAL OPERATION .....15

    ELECTRICAL SETTINGS.....16

        LIMIT SWITCHES AND MAXIMUM LEVEL LAMP .....16

        HOW TO SET LIMIT SWITCHES.....16

        LEVELING CYLINDER STOPS .....17

        LEVELING CONTROLLER FUNCTION .....17

        LEVELING CONTROLLER ADJUSTMENT.....18

    MECHANICAL ADJUSTMENTS.....19

        TREAD WIDTH.....19

        TIRE SELECTION .....19

        HEADER AND COMBINE CONNECTION.....19

        REAR AXLE WEIGHTING .....20

        PADDLE STRIPPERS & NARROWING PLATES .....21

        REAR AXLE EXTENSION POSITIONING .....22

        REAR AXLE TOE IN.....22

        TRANSITION DRIVE CHAIN.....22

        TRANSITION SLIP CLUTCH.....23

        LADDER .....23

        LEVELING CYLINDER SAFETY STOPS .....24

    GENERAL SHIELDING .....24

    HYDRAULIC SETTINGS .....24

    HYDRAULIC HOSES .....25

    HYDRAULIC CYLINDERS.....25

    GREASE LOCATIONS.....26

    GREASE LOCATIONS.....27


    FASTENERS .....28

        TORQUE CHARTS.....29

    TIRE INFLATION.....30

    SCHEMATICS .....31

## SERIAL NUMBER LOCATION



Serial Number Location

Write the serial number and the model number of the Leveling System on the lines provided. If needed, give these numbers to your dealer when you need parts or information for your Leveling System.

---

SERIAL NUMBER

---

MODEL NUMBER

# WARRANTY REGISTRATION



## Warranty Registration

Fill out this card and return it to Hillco Technologies. Also fill out the form below the card and retain it for your records.

Product Purchased \_\_\_\_\_  
 Model # \_\_\_\_\_ Serial # \_\_\_\_\_  
 (The product name, model # and serial # are located on the serial no. tag.)  
 Date of Purchase \_\_\_\_/\_\_\_\_/\_\_\_\_  
 Where purchased? \_\_\_\_\_  
 Purchased by \_\_\_\_\_  
 Mailing Address \_\_\_\_\_  
 Shipping Address \_\_\_\_\_  
 City, State \_\_\_\_\_ Zip \_\_\_\_\_  
 Phone # (\_\_\_\_) \_\_\_\_\_ Fax # (\_\_\_\_) \_\_\_\_\_  
 Where did you hear of this product? \_\_\_\_\_

**IMPORTANT!!** This card must be completed and returned to validate the warranty. Thank you for purchasing this Hillco product.

### OWNER'S OBLIGATION

**WARRANTY REGISTRATION** You must complete the Warranty Registration Card and submit it to Hillco Technologies, Inc. within thirty (30) days of the date of delivery to register the new equipment under Hillco's Warranty Policy.

**Warranty Void if not Registered!**

**MAINTENANCE SERVICE** The operator's manual furnished to you with the equipment at the time of delivery contains important maintenance and service information. You should read the manual carefully and follow all maintenance and service recommendations. Doing so will result in greater satisfaction with your equipment and help to avoid service and warranty problems. Please remember that failures due to improper maintenance of your

# WARRANTY POLICY



## **Statement of Limited Warranty** (North American Harvest Products)

Hillco Technologies, Inc. (Hillco) warrants its new products to be free from defects in material and workmanship for a period of twelve (12) consecutive months following the warranty start date.

The warranty start date for Hillco products invoiced by Hillco from October 1<sup>st</sup> through May 31<sup>st</sup> is the first day of June following the Hillco invoice date, or the first date of use, whichever is earliest. For Hillco products invoiced by Hillco from June 1<sup>st</sup> through September 30<sup>th</sup> the warranty start date is the date of invoice. Once the warranty period has begun, it cannot be stopped or interrupted.

Hillco's obligation under this warranty shall be limited to repairing or replacing, free of charge to the original purchaser, any part that, in Hillco's judgment, shows evidence of such defect. Hillco additionally agrees to repair, at no cost to the original purchaser, any physical damage to the product to which the Hillco product is directly attached provided that the damage is directly attributable to a defect in the design or manufacture of the Hillco product, as determined by Hillco, and that the damage occurs during the effective warranty period of the Hillco product.

Hillco warrants genuine Hillco replacement parts and components to be free from defects in material and workmanship for a period of ninety (90) consecutive days following the Hillco invoice date, or the remainder of the original equipment warranty period, whichever is longer.

### **Limitations to Warranty**

This warranty does not cover:

- 1) Any product damaged by accident, abuse, misuse, negligence, or improper maintenance.
- 2) Any unauthorized product alteration or modification.
- 3) Any unauthorized repairs made with parts other than genuine Hillco parts unless specifically authorized by Hillco.
- 4) Any repairs performed by anyone other than Hillco or an authorized Hillco dealer unless specifically authorized by Hillco.
- 5) Any claims directly resulting from improper installation, except those installations performed by Hillco.

### **Warranty Procedure**

A Hillco Warranty Registration Form must be fully completed and returned to Hillco within 30 days of sale of the product to the retail customer or the first day of use, whichever is earlier.

All warranty claims must be submitted on a fully completed Hillco Warranty Claim Form.

All warranty work must be performed, and claims submitted, within thirty (30) days of the occurrence of the claim and within the warranty period.

All parts removed during warranty repair should be held for a period of sixty (60) days after the warranty claim has been submitted to Hillco.

Hillco reserves the right to either inspect the product at the original retail purchaser's location, or the authorized Hillco dealer's location; or require it to be returned to Hillco, transportation charges prepaid, for inspection.

### **Limitation of Liability**

Hillco makes no express warranties other than those, which are specifically described herein. Any description of the goods sold hereunder, including any reference to buyer's specifications and any descriptions in circulars and other media published by Hillco is for the sole purpose of identifying such goods and shall not create an express warranty that the goods shall conform to such description.

**THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED.** There are no implied warranties of merchantability or fitness for a particular purpose. This warranty states Hillco's entire and exclusive liability and buyer's exclusive remedy for any claim for damages in connection with the sale or furnishing of Hillco products, their design, suitability for use, installation, operation, or for any claimed defects herein. **HILLCO WILL IN NO EVENT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER, NOR FOR ANY SUM IN EXCESS OF THE PRICE RECEIVED FOR THE GOODS FOR WHICH LIABILITY IS CLAIMED.**

No representative of Hillco nor any dealer associated with Hillco has the authority to change the items of this warranty in any manner whatsoever, and no assistance to purchaser by Hillco in the repair or operation of any Hillco product shall constitute a waiver of the conditions of this warranty, nor shall such assistance extend or revive it.

Hillco reserves the right to make improvements in design or changes in specifications at any time, without incurring any obligation to owners of units previously sold.

D-041201LJH01

## **Introduction**

Thank you for choosing the Hillco 2000 Series Leveling System to compliment your farming operation. This product has been designed and manufactured to meet the needs of a discriminating buyer for increasing the performance of a combine.

Safe, efficient and trouble free use of your Hillco 2000 Series Leveling System requires that you and anyone else who will be operating or maintaining the leveling system, read and understand the safety, operation, and maintenance information contained in the Operator's Manual.

**If extra copies of the operator's manual are needed, contact Hillco at 1-800-937-2461 and ask for the document number shown on the cover page of this manual.**




## **HILLCO MODEL 2950 LEVELING SYSTEM**

This manual covers the Hillco 2000 Series Models 2960 (For 9600, 9610, 9650 Walker, & 9660 Walker Combines) and the 2950 (For 9400, 9410, 9450 Walker, 9500, 9510, 9550, CTS & CTSII Combines) Leveling Systems built by Hillco. Use the Table of Contents as a guide when searching for specific information.

Keep this manual handy for frequent reference and to pass on to new operators or owners. Call your Hillco dealer or Hillco if you need assistance or information at 1-800-937-2461.

**OPERATOR ORIENTATION** – The directions left, right, front, and rear, as mentioned throughout this manual, are as seen from the combine operator's seat and facing in the direction of forward travel.

## **SAFETY ALERT SYMBOL**



This Safety Alert symbol means  
**ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**

The Safety Alert symbol identifies important safety messages on the Hillco 2000 Series Leveling System and in the manual. When you see this symbol, be alert to the possibility of personal injury or death. Follow the instructions in the safety message.

## **SIGNAL WORDS**

Note the use of the signal words **DANGER**, **WARNING**, and **CAUTION** with the safety messages. The appropriate signal word for each message has been selected using the following guidelines:

**DANGER** - An immediate and specific hazard, which **WILL** result in severe personal injury or death if the proper precautions are not taken.

**WARNING** - A specific hazard or unsafe practice, which **COULD** result in severe personal injury or death if proper precautions are not taken.

**CAUTION** - Unsafe practices which **COULD** result in personal injury if proper practices are not taken, or as a reminder of good safety practices.

## **OPERATION SAFETY**

1. Read and understand the Operator's Manual and all safety labels before operating the leveling system.
2. Make sure that all controls are in the manual position before starting the combine.
3. Clear the area of all bystanders, especially children, before starting the leveling system and during operation.
4. Make sure all safety shields are in place before operating the combine. Never operate the machine with the shields removed.
5. Keep hands, feet, hair and clothing away from all moving and/or rotating parts.
6. Stay seated in the cab during operation.
7. Operate controls only when sitting in the seat of the combine.
8. To avoid engine damage, do not run the machine for extended periods of time when it is in the leveled over position.
9. Always travel at a safe speed. Use caution when making turns or traversing ditches.
10. There are restrictions as to tread width and tire selection. Refer to page 13 for important information on these restrictions.
11. The use of after-market grain tank extensions is prohibited from use on combines equipped with the Model 2970 leveling system.

## **HYDRAULIC SAFETY**

1. Do not search for high-pressure hydraulic leaks without hand and face protection. A tiny, almost invisible leak can penetrate skin, thereby requiring immediate medical attention. Gangrene may set in, in as few as 3 hours!
2. Use cardboard or wood to detect leaks – never your hands!
3. Double check that all is clear before operating hydraulics.
4. Maintain proper hydraulic fluid levels.
5. Ensure all fittings and hoses are in good repair.
6. Do not make any repairs to the leveling system hydraulic system including: cylinders, valves, hydraulic hoses, adapters, pumps, manifolds, or reservoirs without first contacting your authorized Hillco dealer. These hydraulic components stabilize the chassis of the combine. Improper repair or replacement of these components could lead to uncontrolled leveling of the combine's chassis.

## **SERVICING AND MAINTENANCE SAFETY**

1. Review the Operator's Manual and all safety items before servicing or maintaining the leveling system.
2. Place the Auto/On/Off leveling switch in the "Off" position, stop the combine engine, wait for any moving parts to stop, block the tires, the header, and the cylinder areas before servicing, repairing, adjusting, or maintaining the leveling system.
3. Hydraulic oil is under pressure. Use caution when dealing with the hydraulic system.
4. Keep hands, feet clothing and hair away from all moving and/or rotating parts. Clear the area of bystanders, especially children, when carrying out any maintenance, repairs or making any adjustments.

### *USE PROPER TOOLS*

Use tools appropriate to the work. Makeshift tools and procedures can be a safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use correct size tools. **DO NOT** use U.S. measurement tools on metric fasteners. Avoid bodily caused by slipping wrenches.



---

### *HIGH PRESSURE FLUIDS*

Escaping fluid under pressure can penetrate the skin causing serious injury.

Search for leaks with a piece of cardboard, never your hands.

Relieve pressure before disconnecting hydraulic or other lines.

If an accident occurs consult a doctor immediately. Fluid injection into the skin must be surgically removed within a few hours or gangrene may result.




---

### *SUPPORT MACHINE PROPERLY*

Always use proper lifting and support equipment, when working on jacked up machine.


**DO NOT** support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. **DO NOT** work under a machine that is supported solely by a jack.



---


### *REMOVE KEY*

Always remove the key from the ignition before working on machine.



**USE PROPER LIFTING EQUIPMENT**

Lifting heavy components or parts improperly can cause severe injury or even death.



**REMOVE ALL SPILLED FLUIDS**


Keep work area free of all spilled oil.

Keep all access areas clean and free of obstruction.



**SAE CODE 62 FOUR BOLT FLANGE FITTING TORQUE CHART**

1. Inspect the sealing surfaces for nicks or scratches, roughness or out-of-flat condition. Scratches causes seal wear. Out-of-flat causes seal extrusion. If these defects cannot be polished out, replace the component.
2. Lubricate the o-ring and install into the groove.
3. For split flange; loosely assemble split flange halves being sure that the split flange is centrally located and perpendicular to the port. Hand tighten cap screws to hold parts in place. **DO NOT PINCH O-RING.**
4. For single piece flange; put hydraulic line in the center of the flange and install four cap screws. With the flange centrally located on the port, hand tighten cap screws to hold it in place. **DO NOT PINCH O-RING.**
5. For both single and split flange, be sure the components are properly positioned and cap screws are hand tight. Tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten all cap screws within the specified limits shown in the chart.



**DO NOT USE AIR WRENCHES. DO NOT TIGHTEN ONE CAP SCREW FULLY BEFORE TIGHTENING THE OTHERS. DO NOT OVER TIGHTEN.**

**O-RING BOSS FITTING TORQUE CHART**


**Straight fitting**

1. Inspect O-ring boss seat for dirt or defects.
2. Lubricate O-ring with oil. Place electrical tape over threads to protect O-ring. Slide the O-ring over the tape into O-ring groove of the fitting. Remove tape.
3. Tighten fitting to torque specification shown on the chart.



**Angle fitting**

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer contacts face of boss.
3. Turn fitting head-end counterclockwise to proper angle, maximum of one turn.
4. Hold fitting head-end with a wrench and tighten lock nut and back-up washer to the proper torque specification.



**NOTE: DO NOT ALLOW HOSES TO TWIST WHEN TIGHTENING FITTINGS.**

Torque Value Chart		
Thread Size	Torque	
	N-m	lb-ft
3/8-24 UNF	8	6
7/16-20 UNF	12	9
1/2-20 UNF	16	12
9/16-18 UNF	24	18
3/4-16 UNF	46	34
7/8-14 UNF	62	45
1-1/16-12 UNF	102	75
1-3/16-12 UNF	122	90
1-5/16-12 UNF	142	105
1-5/8-12 UNF	190	140
1-7/8-12 UNF	217	160
NOTE: Torque Tolerance is +/- 10%		

### O-RING FACE SEAL FITTING TORQUE CHART

1. The sealing surfaces must be free of dirt or defects.
2. The O-ring must be free of dirt or defects.
3. Lubricate O-rings and install into groove.
4. Tighten the fitting or nut to torque specification shown on the chart.



**NOTE: DO NOT ALLOW HOSES TO TWIST WHEN TIGHTENING FITTINGS**

O-RING FACE SEAL FITTING TORQUE CHART					
Nominal Tube O.D.				Swivel Nut	
mm	in.	Dash Size	Thread Size in.	N-m	lb-ft
6.35	0.2500	-4	9/16/2018	5.0	3.5
9.52	0.3750	-6	11/16/2016	9.0	6.5
12.70	0.5000	-8	13/16-16	17.0	12.5
15.88	0.6250	-10	1-14	17.0	12.5
19.05	0.7500	-12	1-3/16-12	17.0	12.5
22.22	0.8750	-14	1-3/16-12	17.0	12.5
25.40	1.0000	-16	1-7/16-12	17.0	12.5
31.75	1.2500	-20	1-11/16-12	17.0	12.5
38.10	1.5000	-24	2-12	17.0	12.5
Torque Tolerance is +15 -20%					


## **HIGHWAY OPERATION AND TRANSPORT SAFETY**

1. Check with local authorities regarding combine transport on public roads. Obey all applicable regulations and laws.
2. Check clearance elevations and widths of combine for travel near power lines, bridges, trees, etc.
3. Make sure the Auto/Off/Manual leveling toggle switch is in the "Off" position for all transport and highway travel situations.
4. Always travel at a safe speed. Use caution when making corners or meeting traffic.

## **SAFETY LABELS**

Familiarize yourself with the location of all safety labels. Read them carefully to understand the safe operation of your machine.

### **"Read Operator's Manual" Symbol**




Decals, which display the "Read Operator's Manual" symbol, are intended to direct the operator to the Operator's Manual for further information regarding maintenance, adjustments and/or procedures for particular areas of the leveling system. When a decal displays this symbol refer to the Operator's Manual for


### **TO APPLY NEW OR REPLACEMENT LABELS:**

1. Make sure the label area is smooth by removing any debris such as dirt or old labels.
2. Wash the area with soap and water and then dry it thoroughly.
3. After the area has completely dried, peel the backing off the safety label and place it onto the cleaned area.
4. Make sure all areas of the label have adhered to the machine by pressing down on the entire face of the label, including the corners.

**SAFETY LABEL LOCATIONS**



## SAFETY LABEL SPECIFICATIONS



Label #1  
Part number: LL20-100787  
Locations: 2 (left and right side of combine above front tires)



Label #2  
Part Number: LL20-100783  
Locations: 6 (front and rear of undercarriage and each side of drop axle assembly)




Label #3  
Part number: LL20-10784  
Locations: 2 (left and right side of upper transition face plate)



Label #4  
Part number: LL20-100788  
Locations: 3 (main cylinders and above leveling manifold)



Label #5  
Part number: LL20-100786  
Locations: 1 (front of electrical box)



Label #6  
Part number: LL20-100782  
Locations: 1 (inside cab window beyond console)

**These safety labels should be present and legible at all times. If new labels are needed, or you have any questions concerning safety, please contact Hillco at 1-800-937-2461.**



Label #7  
Part number: LL20-100785  
Locations: 1 (ladder well)

# OPERATION, SETUP, AND MAINTENANCE

## ELECTRICAL OPERATION

### LEVELING SYSTEM CONTROLS

#### MANUAL LEFT / RIGHT LEVELING SWITCH

**LEVEL LEFT:** Push the switch to the left.

**LEVEL RIGHT:** Push the switch to the right.

#### MANUAL/OFF/AUTO LEVELING SWITCH

**AUTO:** Push the Manual/Off/Auto leveling switch to the Auto position to select automatic leveling operation. The automatic leveling controllers monitor changes in slope and automatically keep the chassis of the combine level. The LEFT / RIGHT leveling switch will override the automatic leveling controllers but when this switch is released the controllers will again automatically level the combine chassis.

**MANUAL:** Push the Manual/Off/Auto leveling switch to the Manual position to select manual leveling operation. With the switch in this position the Manual Left/Right leveling switch will level the combine left and right. When the switch is released the combine chassis will maintain the current chassis position and not return to level.

**OFF:** Push the Manual/Off/Auto to the Off position to perform any kind of maintenance to the combine or when transporting the combine.

#### HEADER TRIM SWITCH

The header trim switch is the four-position header control switch mounted in the combine's SR control lever. It is used to raise and lower the header as well as trim the header left and right.

**TILT LEFT:** Push the switch to the left to tilt the header counterclockwise.


**TILT RIGHT:** Push the switch to the right to tilt the header clockwise

#### MAXIMUM LEVEL LAMP

The leveling system is equipped with a maximum level warning lamp. This lamp indicates when the machine has reached its maximum leveling capability.

#### LEVELING SYSTEM FUSE

The leveling system electrical has a fuse located in the right side of the cab control box for protection of the leveling system. If the fuse needs to be changed an **AGC-6A fuse** is required.



## **ELECTRICAL SETTINGS**

### *LIMIT SWITCHES AND MAXIMUM LEVEL LAMP*

The leveling system is equipped with left and right level limit switches that disable the automatic/manual leveling when the combine reaches its maximum leveling capability in either direction. These switches are preset by the installer at either the maximum leveling capability of the combine or in some cases at a lesser angle to provide for proper tire clearance. It is important to note that in the event of a limit switch failure the combine may continue to level to its maximum capability. Care should be taken to make sure tire clearances are adequate in the maximum level position to prevent damage to the tire or chassis in the event that a limit switch failure should occur. The limit switches also actuate the maximum level lamp that indicates to the operator when the combine has reached its maximum leveling capability. The operator should daily level the combine to its maximum level position, with the bulk tank empty, using the manual leveling switch to insure the limit switches and maximum level lamp are operational. The maximum level lamp will only light when the manual switch is held into the left or right leveling position or the system is in the automatic mode when the combine reaches maximum level.

#### **IMPORTANT!**

With certain tire selections the limit switches can be used to prevent the need to modify the sheet metal on the left and right side panels of the combine. Installation of level limit stops is recommended to prevent sheet metal damage in the event of a limit switch failure.

### *HOW TO SET LIMIT SWITCHES*

To set the limit switches, park the combine on level ground and set the parking brake. Then raise the feeder spout and drop the header lift cylinder safety stop. Place the auto/manual-leveling switch in the manual position. Lean the combine to the left until either the maximum leveling capabilities of the leveling system are reached or there is approximately one inch of clearance between the tires and any metal that may interfere with them. Next, shut off the machine. The limit switches are located on each side of the gray controller box near the main pivot pin. Loosen the bolt that holds the left limit switch stop in place. Adjust the left limit switch stop up to the point where you can hear the contacts on the limit switch snap and move slightly past this point. Repeat this process for the right limit switch.

#### **IMPORTANT!**

If Leveling Cylinder Stops are used be sure that the limit switches are set to stop leveling before the stops make contact. Damage to the cylinders or other leveling system components may occur if limit switches aren't set properly.

### *LEVELING CYLINDER STOPS*

If the tire selection that is used on the combine creates sheet metal clearance problems and requires using the limit switches to stop leveling prematurely it is **recommended to use Leveling Cylinder Stops**.


On the Model 2950 and 2960 Leveling Systems the Leveling Cylinder Stops can be clamped on the main leveling cylinders to mechanically stop leveling if the limit switches were to fail. To determine how many spacers are needed to create a mechanical stop follow these steps:

1. Park the combine on level ground and apply the parking brake.
2. Raise the feeder spout and drop the header lift cylinder safety stop.
3. Place the Auto/Manual-leveling switch in the manual position and lean the combine to the left until the limit switch that was set previously stops leveling.
4. Shut off the machine and measure the distance between the packing gland on the rod end of the cylinder and the ring that is welded to the rod end.
5. Write down this dimension and repeat the process for the right side. (Both sides must be measured due to the fact that the combine may level further one direction than the other.)
6. The dimensions obtained will determine how many spacers are needed.

There is no additional charge for the leveling cylinder stops (Call Hillco with dimensions to order).

#### **IMPORTANT!**

If Leveling Cylinder Stops are used be sure that the limit switches are set to stop leveling before the stops make contact. Damage to the cylinders or other leveling system components may occur if limit switches aren't set properly.



### *LEVELING CONTROLLER FUNCTION*

The Hillco Model 2950 & 2960 Leveling Systems are equipped with a proportional leveling system with manual control and automatic with manual override control. The clinometer, located in the control box, monitors changes in slope and corrects the position of the combine's chassis using proportional leveling. The clinometer maintains leveling accuracy to +/- 1/4th degrees by sending the leveling signal to the proportional leveling control valve on the manifold. As the combine reaches higher degrees of being out of level, the clinometer sends more voltage to the directional control valve's coil and pulls the spool open further to allow oil to flow faster and speed up leveling. As the combine gets closer to +/- 1/4th degrees out of level, less voltage is sent to the coil to slow leveling.


## LEVELING CONTROLLER ADJUSTMENT

The clinometer is properly positioned when the combine returns to the level position in the automatic mode from both the left and the right. A 1/4th degree dead band each direction from level in the clinometer will prevent the chassis from returning to absolute level. If the combine does not return to the same level point from each side and the chassis leans more one direction than the other, then follow these adjustment steps:

1. Park the combine on level ground, raise the header, turn off the ignition, block the tires, and lock the feeder lift cylinder. It is often helpful to level the combine at low idle during this process so that the leveling speed is reduced during adjustment.
2. Open the control box and loosen the lower & upper mounting screws that mount the clinometer onto the aluminum plate. The bottom hole in the clinometer is slotted to allow the clinometer to be rotated.
3. Move the bottom of the clinometer in the direction you wish the combine to level. Once the clinometer has been moved and the mounting bolts retightened, level the combine to each side and return to level using automatic leveling and again check for level. It is often helpful to level the combine at low idle during this process so that the leveling speed is reduced during adjustment.
4. Repeat as necessary until the combine sits at the same amount out of level from each direction.

### NOTE!

The 1/4th degree trip angle is adjustable in the clinometer only by a trained technician. This trip angle has been pre-set for maximum performance by Hillco and should not be readjusted without first contacting Hillco.



## ***MECHANICAL ADJUSTMENTS***

### *TREAD WIDTH*

The **Model 2960 Leveling System** is designed around a main undercarriage length of 113.375" or 131.875". The 113.375" undercarriage is designed for use with dual tire packages where 120-180" tread spacing is preferred for 30" rows. Use of the 113.375" undercarriage with duals will limit the leveling capability of the combine from 27% to 23%. The 131.875" undercarriage was designed to move the dual tires outward to 138-198" tread spacing to for the maximum leveling capability of the combine or 27%. The final drives can be mounted directly to the 113.375" and 131.875" undercarriages. **Dual tires are required for all combines equipped with the Model 2960 Leveling System.**

The **Model 2950 Leveling System** is designed around an undercarriage length of 114.5". The 114.5" undercarriage is designed for use with dual tire packages where 120-180" tread spacing is preferred for 30 " rows. Certain dual tire packages may reduce the amount of leveling from 27% to 23%. **Dual tires are required for all combines equipped with the Model 2950 Leveling System.**

### *TIRE SELECTION*



#### **CAUTION!**

All combines equipped with either the Model 2950 or 2960 Leveling System are required to use dual tires. Contact Hillco to insure that you have the proper wheels and tires for your specific combine and header configuration.

### *HEADER AND COMBINE CONNECTION*

Refer to the John Deere Operator's Manual for your model of combine for instructions on connecting the header to the combine.

#### **IMPORTANT!**

Hose lengths must be lengthened to allow for maximum rotation of the header. Check all hoses and wires connected between the combine and the header for proper length when first rotating the header.

All John Deere headers require a Header Kit to function properly during rotation of the transition. Contact your dealer for information on these kits.

## REAR AXLE WEIGHTING

The HILLCO Model 2950 & 2960 Leveling Systems are designed to transfer enough weight to the rear axle of the combine for proper balance that no additional weight is needed. If it is felt that additional weight is needed on the rear axle it can be accomplished by adding:

- 1) Calcium Chloride in Rear Tires
- 2) John Deere Rear Wheel Weights

Use caution when using individual turning brakes. Installation of a Hillco Leveling System transmits additional weight to the rear axle of the combine. Excessive braking to turn can damage your combine chassis.



### **CAUTION!**

**The responsibility for making the final determination of appropriate rear axle weighting lies with the operator.**

When first operating the Model 2950 & 2960 Leveling Systems in hillside conditions, begin operation on gradual slopes and work up to more severe slopes only after you have determined that rear axle weighting is appropriate for downhill maneuvers. The first indication of insufficient rear axle weighting is sluggish or unresponsive steering while traveling down hill. This effect will worsen if the operator decelerates. Make sure rear axle weighting is sufficient for safe down hill maneuvers, under normal deceleration, in your most severe down hill conditions.


### **IMPORTANT!**

**Use of grain tank extensions is strictly forbidden. Use of such extensions voids both the Hillco and John Deere new equipment warranties.**

**PADDLE STRIPPERS & NARROWING PLATES**

The purpose of the Paddle Stripper is to strip viney material from the paddle before it wraps tight around the end of the Beater Shaft, causing premature bearing failure. The Narrowing Plate forces the material in towards the center of the paddles to help prevent material from wrapping.

The Paddle Strippers & narrowing Plates are NOT REQUIRED. They are OPTIONAL and intended for use in viney crops. They can be added or removed at the Operator's Discretion.



**IMPORTANT!**  
Rotate the Beater Shaft One Full revolution after adjusting Paddle Strippers to be sure they don't contact paddles. Adjust Paddle Strippers so they are 1/16 to 1/8 inches from contacting paddle. Improper adjustment may cause damage to the combine.



### *REAR AXLE EXTENSION POSITIONING*

The rear axle on the combine is designed so that the axle extensions may be bolted in two different positions to adjust the rear height of the combine. The rear axle extension position may need to be adjusted after the correct tires and header are installed on the combine. The combine should sit level to two inches high in the rear. If it does not, then the axle extension position will have to be adjusted and the tire size may have to be changed. Consult your combine's operator's manual for more information on the proper stub axle position.

### *REAR AXLE TOE IN*

If the rear tire and wheel size changed after the proper sized rear tires were installed the toe in should be checked. Consult your combine's operator's manual on the correct toe in for your tire and wheel size.

### *TRANSITION DRIVE CHAIN*

Check to see that the transition drive chain is in proper alignment and has proper tension. Misalignment of these sprockets will cause premature wear of the sprockets and chain. Chain tension is maintained with the tensioner that is bolted to the left side of the transition. Tensioner adjustment can be found in the following paragraph.

## **CHAIN TENSIONER ADJUSTMENT INSTRUCTIONS**

### ***Step 1***

Adjust the tensioner to the correct degree of tension by placing a wrench on the square portion of the tensioner body and a second wrench on the mounting bolt.

### ***Step 2***

Apply pressure to the tensioner body in the appropriate direction until the chain is properly tensioned. Note that the tensioner is designed to deflect up to 30 degrees either side of its normal position.

### ***Step 3***


While holding the tensioner body in position, torque the mounting bolt to 60 lb ft.

### ***Step 4***

Before starting the drive, check the nuts on the idler bolt for tightness.

### ***Step 5***

After the drive has been started, visually inspect the tensioner for alignment and proper tensioning.



### *TRANSITION SLIP CLUTCH*

The transition slip clutch is preset at the factory so that damage will not occur to any of the transition drive components; it cannot be adjusted and will never require any adjustment. **See Grease Locations for lubrication information.**

### *LADDER*

If the ladder doesn't extend and retract properly check the fasteners in all of the pivot locations and make sure they aren't over tightened. Over tightening of these fasteners will cause the ladder to bind.

Make sure that the gas-charged struts keep the ladder fully retracted. Replace the struts if they appear to be weak. **If the ladder doesn't fully retract, permanent damage may occur during field operation.**



### *LEVELING CYLINDER SAFETY STOPS*

When the leveling cylinder safety stops are installed on the leveling cylinders, the chassis cannot rotate. The stops must be installed before working on or around the leveling system and also when hauling the combine. It is recommended that the stops be used during long-term storage. When the stops are not being used, they should be stored in the combine cab. The shipping spacers will have to be trimmed if Leveling Cylinder Stops have been used for a mechanical safety stop.



### **GENERAL SHIELDING**

Before operating the combine all shields must be in place and in working condition.

Shield to tire clearance needs to be checked once the correct tires are installed on the combine. Check to see if the clearance is correct by having someone watch the tire and shields as the operator leans the combine to the far right and far left. Some tire selections require limit switches to be set slightly early to allow enough tire clearance between the left and right front side panels.

### **HYDRAULIC SETTINGS**

Refer to the Hydraulic Safety section located towards the front of this manual for precautions regarding the hydraulic system.

The Model 2960 & 2950 Leveling Systems use an auxiliary pump and a stand-alone manifold for the leveling hydraulic requirements. The header trim circuit uses the Contour Master Valve, which is located in the main hydraulic stack valve on the left side of the combine and the existing main pump. The hydraulic schematic at the end of this manual covers the leveling system and header trim circuitry. Consult your John Deere Technical manual or contact your John Deere dealer for diagnostics and maintenance regarding the remainder of the hydraulic system.

#### **IMPORTANT!**

All adjustments on the hydraulic system are preset at the factory for optimal leveling and header trim performance. **DO NOT MAKE ANY ADJUSTMENTS TO THESE SETTINGS WITHOUT FIRST CONTACTING YOUR AUTHORIZED HILCO DEALER.**

## **HYDRAULIC HOSES**

Inspect the hydraulic system for leaks, damaged hoses, improper routing, and loose fittings.

Hydraulic hoses that are not routed correctly could become worn from working against abrasive edges or moving parts. If abrasions or holes do occur, the hydraulic hoses can only be repaired by replacement. **Do not attempt repairs with tape or cements.** High pressure will burst such repairs and cause system failure and possible injury.

Hydraulic Hose Connections – When tightening loose hoses on the cylinders, pump, etc., always use one wrench to keep the hose from twisting and another wrench to tighten the union. Excessive twisting will shorten hose life and allow the fitting to loosen during operation. Do not over-tighten fittings or adapters.

Refer to the John Deere Operators Manual for information regarding hydraulic oil, check intervals, and reservoir fluid levels. High speed leveling, low speed leveling and header trim speeds are preset at the factory. If different speeds are desired please contact your Hillco dealer.

## **HYDRAULIC CYLINDERS**

### **IMPORTANT!**

Each leveling cylinder is equipped with a safety valve that is in place to prevent unintentional leak down of the cylinder. These safety valves are preset at the factory, and should not be adjusted.




### **DANGER!**

Do not make any repairs to the cylinders, disconnect valves, or disconnect any hoses connected to the cylinders, counterbalance valves, bulkhead mount or manifold without first contacting your authorized Hillco dealer. These hydraulic components stabilize the chassis of the combine. Improper repair or replacement of these components could lead to uncontrolled leveling of the combine's chassis. The leveling system's shipping spacers can be used to prevent accidental tipping of the combine during repair.


**Hydraulic schematics for this leveling system are located at the end of this manual.**

## GREASE LOCATIONS

Use NLGI No. 2 Multi-Purpose Lithium Grease.



Slave  
Cylinder  
⌚ 50 hrs.  
2 Zerks



Main leveling cylinders  
⌚ 50 hrs. 2 Zerks


## GREASE LOCATIONS

Use NLGI No. 2 Multi-Purpose Lithium Grease.



### IMPORTANT!

Recommended Oil Change Interval for the Over-Hung Load Adapter is 1000 Hrs. Please order Part Number LA-260401 for 2.5 fl. oz. of replacement oil. Do Not Over or Under fill or Damage to the Over-Hung Load Adapter may occur.



## ***FASTENERS***

### Check Bolt Tightness

- After the first 10 hours of operation
- Every season

The following bolts are torqued to special specifications because of the application in which they are used.

Transmission Mount Bolts:	John Deere Torque specifications
Final Drive Housing Bolts:	John Deere Torque specifications
Drive Wheel Hub Bolts:	John Deere Torque specifications
Steering Wheel Hub Bolts:	John Deere Torque specifications
Rear Axle Extension Bolts:	John Deere Torque Specifications
Unloading Auger Drive Shaft Locknut::	John Deere Torque Specifications

### **IMPORTANT!**

Consult your John Deere Operator's Manual to verify that the correct bolts and spacers are used for the wheel application that is on the combine.

The following page shows torque specifications for both metric and standard fasteners. Use these charts for checking torques on bolts not shown above.

**TORQUE CHARTS**

<b>Metric Bolt and Cap Screw Torque Values</b>																
	Class 4.8				Class 8.8				Class 10.9				Class 12.9			
	Lubricated		Dry		Lubricated		Dry		Lubricated		Dry		Lubricated		Dry	
Size	N-m	lb-ft	N-m	lb-ft												
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	190
M16	100	73	125	92	190	140	240	175	275	200	350	255	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	325	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

"Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.  
 "Dry" means plain or zinc plated without any lubrication.

<b>Unified Inch Bolt and Cap Screw Torque Values</b>																
	Grade 1				Grade 2				Grade 5, 5.1, or 5.2				Grade 8 or 8.2			
	Lubricated		Dry		Lubricated		Dry		Lubricated		Dry		Lubricated		Dry	
Size	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	240	175	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	400	300	510	375	400	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

Grade 1 applies for hex cap screws over 152mm (6in.) long, and for all other types of bolts and screws of any length.  
 Grade 2 applies for hex cap screws (not hex bolts) up to 152mm (6in.) long.  
 "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.  
 "Dry" means plain or zinc plated without any lubrication.

**Torque specifications for certain fasteners may vary from these charts. Do not use any of the bolt torque specifications listed in this chart without first reading the bolt torque information listed on the previous pages.**

## **TIRE INFLATION**

Keep the tires properly inflated to the pressure shown in the combine's Operators Manual for the front and rear tires. Both under-inflation and over-inflation are detrimental to tire life.

Don't re-inflate a tire that has been run flat or when there is obvious or suspected damage to the tire or wheel components. Check the tire pressure weekly or after 50 hours of operation.



### **WARNING!**

When inflating tires, use a clip on air chuck and extension hose long enough to allow you to stand to one side and NOT in front or over the tire assembly. Use a safety cage if available.



### **WARNING!**


A tire can explode during inflation and cause serious injury or death. Never increase air pressure beyond 35 PSI to seat the bead on the rim. Replace a tire if it has a defect. Replace a wheel rim, which has cracks, wear or severe rust. Make sure that all the air is removed from a tire before removing the tire from the rim. Never use force on an inflated or partially inflated tire. Make sure the tire is correctly seated before inflating.

**SCHEMATICS**

**Model 2960 Electrical Leveling Circuit Schematic (9000 & 10 Series)**

FOR WALKER COMBINES 9500 & 9510 (660201- ); 9600 & 9610 (660301- )

S/N 2960-0027 thru 2960-0036; 2950-1007




# Model 2960 Electrical Circuit Schematic (Early 50 Series)



FOR WALKER COMBINES 9550 ( -695200); 9650 ( -695300)

S/N 2960-0027 thru 2960-0036; 2950-1007

Header Trim Circuit - See Combine Electrical Schematic for Contour Master



**Model 2960 Hydraulic Circuit Schematic**  
 S/N 2950-1007; 2960-0027 thru 2960-0036 (Excludes S/N 2960-0035)



**Notes**

**Notes**